


BRAVO BAT-MC64

TECO64 Schematic & parts list



NO.	Description	Qty	NO.	Description	Qty	NO.	Description	Qty	NO.	Description	Qty
1	Bolt	1	23	Piston	1	45	Limit seat	1	67	Nail rail I	1
2	Cover	1	24	Sealing ring	1	46	Pin	2	68	Nail rail II	2
3	Air Deflector	1	25	Gun body	1	47	O-ring	3	69	Bolt	2
4	Bolt	4	26	Bumper	1	48	Trigger plate	1	70	Locating seat	1
5	Washer	4	27	Nose	1	49	Trigger	1	71	Plate	1
6	Top Cap	1	28	Nose Cover	1	50	Roll pin	1	72	Roll pin	2
7	Valve spring	1	29	Roll pin	1	51	Roll pin	1	73	Pusher seat	1
8	O-ring	1	30	Spring washer	4	52	O-ring	1	74	Fixed plate	1
9	Head Valve Piston	1	31	Bolt	4	53	O-ring	1	75	Pin	1
10	O-ring	1	32	Bolt	2	54	Valve seat	1	76	Spring	1
11	O-ring	1	33	Spring washer	2	55	O-ring	1	77	Washer	1
12	O-ring	1	34	Safety nose	1	56	O-ring	1	78	Pin	1
13	Head Valve Piston Seat	1	35	Spring	1	57	O-ring	1	79	Pusher	1
14	Piston Gasket	1	36	Safety	1	58	Shuttle Valve	1	80	Spring	1
15	Bolt	1	37	Bolt	2	59	Spring	1	81	O-ring	1
16	Location ring	1	38	Safety holder	1	60	O-ring	1	82	End cap	1
17	Cylinder	1	39	Spring	1	61	Trigger Valve Stem	1	83	Washer	4
18	O-ring	1	40	Roll pin	2	62	O-ring	1	84	Bolt	4
19	Collar	1	41	Limit cover	1	63	Trigger Seat	1	85	Air inlet plug	1
20	O-ring	1	42	Spring	1	64	Nut	3	86	Air inlet plug sleeve	1
21	Cylinder Sealing ring	1	43	Limit lever	1	65	Magazine	1	87	Housing handle sleeve	1
22	O-ring	1	44	Connection plate	1	66	Bolt	1			